Pump	Pump Duty	Continuously rated
	Max temp	96° C
	Operating temp	85° C
Electrical	Phase	Single 239 Volts 50HZ
	Current	2.45 Amps FLC
	Motor output	0.4kW
	Pump speed	2800 RPM
Flow and Pressure	Max input flow	45 Litres per minute
	Output flows	50 Litres per minute @ 7M head
	BMS high water	Available on request
Control	Method	Float switch
Cabinet	Outer casing	M.D.P.E.
	Capacity	15 Litres
	Dimensions CB4 & CB7	H:470mm W:250mm D:450mm
	Inlet water connection	1½" connection (Deflector and connector supplied)
	Outlet water connection	¾" BSP PVC

Pumping capabilities

Having an operational ability to pump away to a 7 metre head at up to 50 litres per minute and to withstand water temperatures up to 96 degrees centigrade together with a choice of capacities to suit any size oven means the CombiPump series is the ideal alternative to expensive alterations of existing drainage systems.

*Figures are approximate and for indication only, volumes may vary dependant on water temperature and contaminants.

This unit is a waste water pump specifically designed for combination oven units, it is not a food disposal unit or macerator.

Regular cleaning may be required, please test the water temperature before inserting hands into the unit.

Outlet pipe size minimum 15mm

Maximum straight up head is 7 Metres

Maximum pipe run is 10 metres and should include an air gap or Tundish.

Restriction from waste or sediment accumulated in the pipework could affect the pump operation and is not covered by the warranty on the unit.

In the event of the pump failing to operate when fitted to long runs of pipework on the outlet, the pump can be tested easily by disconnection of the outlet and connection of a short piece of hose into a bucket to discount outlet pipework issues.

Safety

- This unit must be operated by a competent person and must not be used in any fashion other than its intended use.
- Any modifications to this unit could cause a malfunction, and cause danger to the operator.
- The electrical installation must be carried out in accordance with the national electrical regulations.
- The electrical installation must be carried out by a qualified person.
- This unit should be installed in line with a 30mA residual current device (R.C.D. not supplied).
- Ensure electrical supply is isolated before carrying out any maintenance on this unit.
- This unit must be earthed correctly.

FAQ's

Q: Can I connect 2 appliances to one Combipump?

- A: Yes providing outlets from the 2 appliances merge into a single inlet to the Combi pump and the total incoming water is within the capacities of the pump
- Q: What is the maximum number of bends I can have in the pipework taking the water away from the Combipump?
- A: Ideally there will be no bends in the pipe run. Any bends in the pipe run will reduce the efficiency and head distance of the Combipump.
- Q: What is the warranty period on a Combipump?
- A: Combipumps come with a 12 months parts and labour warranty against manufacturing faults.
- Q: Will my Combipump need servicing or cleaning?
- A: Although there is no regular servicing needed on the Combipump, due to the nature of the discharged water it may require regular cleaning to remove food or fatty deposits which may cause the pump to malfunction. Please contact WaterCare service department for a quote.

 Email: service@watercare.co.uk



WASTE WATER MANAGEMENT







Scan here for installation video





Introduction

The WaterCare CombiPump series has been designed and developed by our own research and development team at the request of a leading combination oven manufacturer specifically requiring waste water from their oven to be pumped away at a height of just 40MM from the floor.

The CombiPump range has become an almost essential part of any commercial kitchen set up where floor gulley drainage is absent or where ovens are sited away from the drainage points of the kitchen such as islands.

Either CombiPump System can be installed in a convenient position as your chosen installer can locate the inlet fittings.

The new improved Combi Pump range has a capacity to pump away up to 50 l/pm which not only means it can now be connected to 2 ovens but also gives it the versatility to be used in various other circumstances where drain water is required to be removed and no immediate drainage is available.

Combipump selection & application

The EWC Combi Pump is available in two colour coded models for easy identification. The CombiPump4 comes in a Light Blue Cabinet and the CombiPump7 in a distinctive Midnight Blue

The CB4 is designed to be used on ovens where the waste outlet from the oven is as low 40mm from the floor and requires the pump to activate at that level in order to prevent backflow into the oven.

The CB7 allows for a waste outlet up to 70mm with the pump activating at this higher level.



Installation

THIS UNIT MUST BE FITTED WHERE ANY WATER SPILLAGE WILL NOT CAUSE DAMAGE

NB. ONLY ONE INLET CAN BE DRILLED INTO THE CABINET. IF CONNECTING TO 2 OVENS THE OUTLETS FROM THEM MUST MERGE PRIOR TO THE COMBI PUMP INLET.

Consideration should be made when positioning the CombiPump to allow for access for servicing and maintenance.

- 1) Position the CombiPump in the required area and using the diagram below or the supplied template. Decide where the inlet position will be made.
- 2) Drill the desired inlet hole into the holding tank dependant on the model and fit the deflector supplied. NB See information on next page for minimum inlet heights.
- 3) Inlet MUST NOT be drilled in hatched areas or anywhere on Side D. This will damage the pump void any warranty and result in breakdown of the unit.

Minimum inlet heights

CombiPump 4: The height of the inlet on the Combi 4 should be drilled no lower than 70 mm centre line. The 70 mm should be measured from the bottom of the cabinet upwards. Pump activation 40mm.

CombiPump7: The height of the inlet on the Combi 7 should be drilled no lower than 190 mm centre line. The 190 mm should be measured from the bottom of the cabinet upwards. Pump activation 75mm.


The CombiPump comes with its own inlet placing template to ensure correct positioning or you can follow the guidelines as below:



HATCHED AREAS INDICATE WHERE INLET CONNECTIONS ARE NOT PERMITTED









To rest pump

Should you need to reset the pump: remove the black side cover by pulling gently but firmly back on the manual pump activation arm – and then ensuring that the float moves freely up and down. Replace cover by clicking cover into base and pushing top back so cover relocates onto main body. Check activation by raising the manual pump activation arm.

Dimensions & connections

Height 470mm, Width 250mm, Depth 450mm. Inlet 1.5" with supplied Deflector Outlet 3/4 " BSP to 15mm or 22mm pipe. Airgap required at top of run. Run must be vertical with no bends.

Outlet pipe size	Head	Capacity
15mm	Table top	406x170

Where applicable, a Mesh Filter is required to be installed on the Tundish or Oven Outlet. Any damage to the internal pump deemed to be a result of particles or excess food waste will void the manufactures warranty.







